



## RECOMENDATORY SETTER PARAMETERS FOR ABEZETA CTP EVOLUTION

Plate Setter Parameter	KODAK	SCREEN PTR8600	Heidelberg	Heidelberg OEM BY SCREEN	LUSCHER
(W)power	Wpower=10~15W	Power=90~98%	110-145MW	Power=90~98%	800MW
Zoom	N/A	Zoom=1200 (According to actual)	N/A	Zoom=1200 (According to actual)	N/A
DS	185rpm	800rpm	360-420rpm	800rpm	200~350rpm
Focus(Sd)	Sd=0	Focus=2345 (According to actual)	Focus=280	Focus=2345 (According to actual)	Focus=6.5~7.5 (According to actual)
Sr	0.08~0.14	N/A	N/A	N/A	N/A
Temp of Dev	25±2℃	25±2℃	25±2℃	25±2℃	25±2℃
Time of Dev	30-45sec.	30-45sec.	30-45sec.	30-45sec.	30-45sec.
Resolution	1%~99%	1%~99%	1%~99%	1%~99%	1%~99%