



Colenta®

EASY CLEAN Algae AD

A Highly Concentrated Wash Tank Additive for use with the Colenta Easy Clean Algae Pump System or Similar

Helps Keep Processor Wash Tanks and Rollers Clean and Free from Algae Bio-Slime



Stops the Formation and Re-formation of Sludge and Bio-Slime in Wash tanks and on Wash Rack Rollers.

Rapid Cleaning Agents Remove Algae Slime & Sludge With water softening agents to keep wash tanks scale free

Easy Clean Algae AD: Safe, Non-Toxic, Non-Corrosive, Bio-Degradable

A highly concentrated, blend of unique cleaning agents. Rapidly breaks down the bio-film which causes slimy, clogging bio-slime. Regular use keeps wash/rinse water clean and fresh.

Safe for use in all NDT and X-Ray Processors, Photographic Film and Paper Processors and in Ultrasonic, Inspection and Static Tanks.

Proven safe. **Easy Clean Algae AD** will not cause film or print instability and is left in the tanks during processing. No need to drain before use.

1. Automatic Dosing: For use through the **Colenta Easy Clean Algae Pump System**. Our dosing system automatically doses **Easy Clean Algae AD** into the wash water supplying the wash tank. This keeps the entire wash water system including tank, overflow, pipes and drains spotlessly clean 24/7. Eliminates the option of hand dosing and its required manual procedures. For full details on the **Pump System** please see the separate data sheet.

2. Manual Dosing: **Easy Clean Algae AD** can also be used without the **Pump System** to hand dose wash tanks. Add 25ml daily to each 50 litres wash water.

3. Static, Inspection and Ultra Sonic Tanks. 1 litre treats up to 1,000 litres water. Added to clean water to stop slime build-up.

STOPS!
Bio-Slime
Problems in
Wash/Static
Tanks

STOPS!
Expensive
Downtime

STOPS!
Hand
Washing

STOPS!
Slippage &
Jamming of
Rollers

STOPS
Blocked
Overflow &
Flooding