

# EASY CLEAN Concentrate

## Deep Cleaner & Descaler

**Deep Cleans & Removes Scale deposits in the many types of Film, Plate and Paper Processors used in the PCB/NDT/Medical X-Ray/Photo/Print industries.**



**Foams – Clings - Cleans  
Easy Clean Concentrate  
Foaming Spot Cleaner & Processor  
Rack / Tank Soak Cleaner**

### Film Processors

Easy Clean CONCENTRATE is designed to soak away the heavy deposits of chemical residue that can build up within a processor and is a very effective cleaning and removal agent for calcium scale on the surface of wash tanks. Available in 1 litre trigger foaming bottles for easy use during the cleaning and maintenance of a processor (for dye staining on rollers and processor casings use Easy Clean GENERAL).

Easy Clean CONCENTRATE Rapidly dissolves away all traces of heavily oxidised sticky developer, chemical build-up from racks and tanks and algae or calcium build-up on racks or in wash tanks. Easy Clean CONCENTRATE also de-scales pipe-work and heat exchangers.

### Water Scale, Calcium & Algae Scale Remover

Use Easy Clean CONCENTRATE in a soak solution 1:10 to soak away the contamination from wash tanks and racks. Cleaned metal will return to its original brightness. After use simply put to drain.

### Soak Clean with Easy Clean CONCENTRATE Solution @ 1:5 to 1:10 dilution with water

1. Remove racks from tanks and soak for 2-4 hours.
2. For a total deep clean and to de-scale pipe work and re-circulation system remove chemistry from tanks leaving the racks in place. Make up solution in tanks. Turn processor on for 5-10 minutes to allow solution re circulate. Switch processor off and allow to stand for between 2-4 hours. Drain down and thoroughly rinse off all the racks and tanks.

### Spot Clean Racks with Easy Clean CONCENTRATE 1 litre Foaming Bottle

The easy to use Colenta Easy Clean Concentrate, coats the rack components with a fast acting, penetrating soft clinging foam. Remove the rack to be cleaned. Rinse off excess chemistry. Foam Concentrate onto rack, turning rollers to ensure even coverage. Leave until contamination has dissolved (this could be from 30-120 mins depending on the deposit being removed) then pressure rinse off with fresh/clean water.

**Note:** Whilst Easy Clean CONCENTRATE has no unpleasant odour, dissolving chemistry on the part being cleaned does and therefore always use Easy Clean Concentrate in well ventilated areas or use the soak method with CONCENTRATE as described above.

**Note:** For silver build-up on racks and tanks use Colenta Easy Clean SYSTEM.