Aditifs and cleaners G4500c

Technical infosheet G4500c

Description: G4500c is a Graphic concentrated developer tank cleaner.

It is Ecological approved an contains no toxic ingreadienst.

Applications: Used for all graphic developer tanks, especially designed for Silver deposid remov

ing.

Used in combination with:

Developers: Most Graphic developers as there are: ACD, ASD and G101c.

Using conditions: Dilution: 5 liter part A and 5 liter part 6 together k | h &0 hc | \$ litres water

Working temperature: 35°C:95 °F

Storage conditions: always store G4500c in an frost-free environment. Precipitation will occur if the

solution has been frozen.

Disposing: Concentrate or used G4500c solution can be disposed together with the waste

fixer.

Shelf life: 30 months after manufacturing fcdYbYX VchhYq a i chVY i chX k lh\lb %nYUf\.

Sales packaging:

Chemistry	ABC code	Packaging	Dilution
G4500c	4NLNP	1 x 5l A /1 x 5l B	5l A + 5l B makes 30 to 40 l

Precautions: avoid contact with skin. After contact rince thouroughly with water.

Read the MSDS (Material Safety Data Sheet)

User instruction:

- 1. Empty the dirty developer tank and rinse with a little water.
- 2. Leave the rack in the tank and fill the tank with 2,5 liter part A + 10 liter water and 2,5 liter part B per 15 to 20 liters depending on tankcapacity. Top with water.
- 3. Let the processor run for 30 to 60 minutes at the normal working temperature. (min. 35°C).
- 4. Drain the solution into the waste fixer.
- 5. Rinse sincerely and close the tank.
- 6. Fill the tank with tap water and let run for 5 minutes.
- 7. Empty the tank in the waste fixer...
- 8. Rinse carefully, make the circulation pump run for a minute or so.
- 9. Repeat step 6 once more. If not you risk to damage the developer when refilling.
- 10. Refill the developer.