# DuPont<sup>™</sup> Pyralux<sup>®</sup> FR Sheet Adhesive

flexible composites

# **Technical Information**

#### **Description**

DuPont<sup>™</sup> Pyralux<sup>®</sup> FR sheet adhesive is a proprietary, flame-retardant, B-staged modified acrylic adhesive. Sheet adhesive is used primarily to bond flexible inner layers of multilayers, as well as to bond stiffeners and heat sinks to flexible circuits and rigid boards.

#### Construction

Pyralux® FR sheet adhesive is coated on release paper and is available in a variety of adhesive thicknesses; see Table 1.

The product code must be used when ordering sheet adhesive from DuPont.

#### Packaging

Sheet adhesive is supplied on 24 in (610 mm) wide by 250 ft (76 m) long rolls, on nominal 3 in (76 mm) cores. Narrower widths or cut sheets are also available by special order.

## **Typical Data**

Each manufactured lot of sheet adhesive is certified to IPC specifications and tested according to IPC Test Method TM-650. See Table 2.

Table 1 **Sheet Adhesive Product Codes** 

Product Code	Adhesive	IPC
	mil (µm)	Certification*
FR0100	1 (25)	Yes
FR0200	2 (51)	Yes
FR0300	3 (76)	Yes
FR0400	4 (102)	Yes
FR1500	1/2 (13)	Yes
FR1700	.7 (18)	Yes

\*Certified to IPC-4203/18: "Adhesive Coated Dielectic Films for Use as Cover Sheets for Flexible Printed Circuits and Flexible Adhesive Bonding Films."

Exception: the DuPont flow requirement, using IPC-TM-650, Method 2.3.17.1, is 10.0 mils/mil of adhesive thickness

Property	Pyralux <sup>®</sup> FR Sheet Adhesive P Typical Coverlay Value	Test Method
Flammability*	VTM-0	UL94
Peel Strength** After lamination After soldering	 1.6 N/mm (9 lb/in) 1.6 N/mm (9 lb/in)	IPC-TM-650, No. 2.4.9 Method B Method D
Solder Float Resistance 10 sec at 288°C (550°F)	Pass	IPC-TM-650, No. 2.4.13 Method B
Adhesive Flow, µm/µm (mil/mil)	4.0	IPC-TM-650, No. 2.3.17.1
Thickness Tolerance	±10%	IPC-TM-650, No. 4.6.2
Dielectric Constance (at 1 MHz)	3.5	IPC-TM-650, No. 2.5.5.3
Dissipation Factor (at 1 MHz)	0.02	IPC-TM-650, No. 2.5.5.3
Dielectric Strength	118 kV/mm (3000 V/mil)	ASTM D-149
Insulation Resistance (at ambient)	10 <sup>6</sup> megohms	IPC-TM-650, No. 2.6.3.2
Volume Resistivity (at ambient)	10 <sup>9</sup> megohm-cm	ASTM D-257
Surface Resistance (at ambient)	10 <sup>7</sup> megohms	ASTM D-257

Table 2

\*Pyralux® FR0200 and FR0300 meet UL 94 VTM-0 criteria.
\*\* Laminating Conditions: 14 kg/cm<sup>2</sup> (200 psi), 182°C (360°F), 1 hour to treated side of 1 oz RA copper foil.
The values in Table 2 represent a typical 1 oz. RA copper foil, 1 mil adhesive and 1 mil Kapton® construction.

A Certificate of Conformance is available with every batch. Complete material and manufacturing records for each lot, with samples of finished product, are retained for reference purpose. The roll labels contain the lot number, DuPont order number, customer order number, IPC specification, customer specification, and customer part number; save these labels for reference in case of inquiries.

#### Processing

Laminating conditions for DuPont<sup>™</sup> Pyralux<sup>®</sup> flexible composites are typically in the following ranges:

Part Temperature:	182–199°C (360–390°F)
Pressure:	14–28 kg/cm² (200–400 psi)
Time:	1–2 hours, at temperature

Pyralux<sup>®</sup> FR can be processed like Pyralux<sup>®</sup> LF. Refer to publication "Pyralux<sup>®</sup> Flexible Composites Technical Manual" for further processing details.

## **Storage Conditions and Warranty**

Pyralux<sup>®</sup> FR flexible laminates should be stored in the original packaging at temperatures of 4–29°C (40–85°F) and below 70% humidity. The product should not be frozen and should be kept dry, clean and well protected. Subject to compliance with the foregoing handling and storage recommendations, DuPont's warranties, as provided in the DuPont Standard Conditions of Sale, shall remain in effect for a period of two years following the date of shipment.

### Safe Handling

Pyralux<sup>®</sup> FR coverlay, sheet adhesive, and bond ply contain a B-staged adhesive. Since B-staged adhesive contains trace quantities (parts per million) of unreacted monomers, operators should take care to minimize contact.


Pyralux<sup>®</sup> FR copper-clad laminates contain fully cured (C-staged) adhesive.

Although DuPont is not aware of anyone developing contact dermatitis when using Pyralux<sup>®</sup> FR products, some individuals may be more sensitive than others. Anyone handling Pyralux<sup>®</sup> FR copper-clad laminates should wash their hands with soap before eating, smoking, or using restroom facilities. Gloves, finger cots, and finger pads should be changed daily. Clothes should be washed frequently. The unreacted acrylic monomer in the adhesive may impart a mild odor when the release film or paper is removed. We recommend that areas where B-staged materials are used, as well as lay-up and lamination areas, be well ventilated with a fresh air supply.

Pyralux<sup>®</sup> adhesive is cured during lamination. The curing reaction does not produce any vapors, although impurities may volatilize. When drilling or routing parts made with Pyralux<sup>®</sup> FR flexible composites, provide adequate vacuum around the drill head to minimize worker exposure to adhesive dust.

Thin copper-clad laminates can have sharp metal edges. People handling these materials should be cautioned and provided with suitable gloves to prevent cuts.

Pyralux<sup>®</sup> FR flexible composites DO NOT contain polybrominated biphenyls (PBBs), polybromined biphenyl oxides (PBBOs), or polybrominated diphenyl ethers (PBDEs).



For more information on DuPont<sup>™</sup> Pyralux<sup>®</sup> flexible circuit materials , please contact your local representative, or visit our website:

#### <u>Americas</u>

DuPont Electronic Technologies 14 T. W. Alexander Drive Research Triangle Park, NC 27709 Tel: 800-243-2143

<u>Europe, Middle East & Africa</u> DuPont de Nemours (Luxembourg) s.à r.l. Rue Général Patton, Contern L-2984 Luxembourg Tel: +352 3666 5935

Japan DuPont KK Sanno Park Tower 11-1, Nagata-cho 2-chome Chiyoda-ku, Tokyo 100-6111 Tel: 81-3-5521-8660

#### <u>Taiwan</u>

DuPont Taiwan Hsinchu Branch. #2, Li-Hsin 4th Rd., Hsinchu Science Park, Hsinchu 30078, Taiwan Tel: 886-3-5793654 India E.I.DuPont India Limited 1001-1012 "Meadows", 10th Floor Sahar Plaza Complex Andheri-Kurla Road, Andheri (East) Mumbai 400 059, India Tel: 91-22-6751-5000 DID: 91-22-6751-5038 Fax : 91-22-67101937

China DuPont China Holding Co., Ltd. Shanghai Branch Bldg. 11, 399 Keyuan Road Zhanghai Hi-Tech Park Pudong New District Shanghai 201203, China Tel: 86-21-38622720 Korea

DuPont Korea Inc. 4/5 Floor, Asia Tower #726, Yeoksam-dong, Kangnam-ku, Seoul 135-082 Korea Tel: 82-2-2222-5224

Singapore DuPont Singapore Pte, Ltd. 1 HarbourFront Place #11-01 HarbourFront Tower One Singapore 098633 Tel: 65-6586-3091

# pyralux.dupont.com

Copyright ©2012 DuPont or its affiliates. All rights reserved. The DuPont Oval, DuPont™, The miracles of science™, Pyralux® and Kapton® are registered trademarks or trademarks of E.I. du Pont de Nemours and Company or its affiliates.

NO PART OF THIS MATERIAL MAY BE REPRODUCED, STORED IN A RETRIEVAL SYSTEM OR TRANSMITTED IN ANY FORM OR BY ANY MEANS ELECTRONIC, MECHANICAL, PHOTOCOPYING, RECORDING OR OTHERWISE WITHOUT THE PRIOR WRITTEN PERMISSION OF DUPONT. Caution: Do not use in medical applications involving permanent implantation in the human body. For other medical applications, see "DuPont Medical Caution Statement," H-50102.

This information is based on data believed to be reliable, but DuPont makes no warranties, express or implied, as to its accuracy and assumes no liability arising out of its use. The data listed herein falls within the normal range of product properties but should not be used to establish specification limits or used alone as the basis of design. Because DuPont cannot anticipate or control the many different conditions under which this information and/or product may be used, it does not guarantee the usefulness of the information or the suitability of its products in any given application. Users should conduct their own tests to determine the appropriateness of the product for their particular purposes.

This information may be subject to revision as new knowledge and experience become available. This publication is not to be taken as a license to operate under, or recommendation to infringe, any patent.

H-73235-7 05/12

