

DuPont™ Pyralux® FR

Flame Retardant Acrylic-Based Coverlay

Flexible Circuit Materials

Product Description

DuPont™ Pyralux® FR Coverlay features DuPont™ Kapton® polyimide film, coated on one side with a proprietary flame retardant B-staged modified acrylic adhesive. This coverlay can be used to encapsulate etched details in flexible and rigid-flex multilayer constructions for environmental protection and electrical insulation.

Key Features and Benefits

- · Flame retardant modified acrylic adhesive composition
- · Excellent bond strength affords high reliability
- · Able to withstand multiple lamination cycles
- No refrigeration required for storage
- · Certified to IPC-4203/1
- · UL 94 VTM-0, UL File E124294
- · RoHS Compliant

Packaging

Pyralux® FR Coverlay is supplied on 24 in (610 mm) wide by 250 ft (76 m) long rolls, on nominal 3 in (76 mm) cores. Narrower widths or cut sheets are also available by special order.

Storage Conditions and Warranty

Pyralux® FR Coverlay should be stored in the original packaging at temperatures of 4 - 29 °C (40 - 85 °F) and below 70% humidity. The product should not be frozen and should be kept dry, clean, and well-protected. Subject to compliance with the foregoing handling and storage recommendations, DuPont's warranties, as provided in the DuPont Standard Conditions of Sale, shall remain in effect for a period of two years following the date of shipment.

Processing

Lamination conditions for DuPont™ Pyralux® FR flexible circuit materials are typically in the following ranges:

Part Temperature:	182 - 199 °C (360 - 390 °F)
Pressure:	14 - 28 kg/cm² (200 - 400 psi)
Time:	1 - 2 hours, at temperature

Pyralux® FR Coverlay processing guide available from your DuPont sales representative.

Table 1 - Standard Pyralux® FR Coverlay Offerings

Product Code	Adhesive Thickness µm (mil)	Kapton® Thickness μm (mil)
FR7013	25 (1.0)	13 (0.5)
FR0110	25 (1.0)	25 (1.0)
FR0120	25 (1.0)	51 (2.0)
FR0130	25 (1.0)	76 (3.0)
FR0150	25 (1.0)	127 (5.0)
FR7082	51 (2.0)	13 (0.5)
FR0210	51 (2.0)	25 (1.0)
FR0220	51 (2.0)	51 (2.0)
FR0230	51 (2.0)	76 (3.0)
FR0250	51 (2.0)	127 (5.0)
FR0310	76 (3.0)	25 (1.0)
FR7001	13 (0.5)	13 (0.5)
FR1510	13 (0.5)	25 (1.0)
FR7332	19 (0.75)	13 (0.5)

Pyralux® FR Coverlay Construction Selection

A variety of Pyralux® FR Coverlay constructions are commercially available. For help beyond the standard offerings in Table 1, please use the Laminate Product Selector at pyralux.dupont.com to identify the appropriate product code for your coverlay solution.



Safe Handling

Prior to handling, DuPont recommends referencing the Pyralux® Safe Handling Guide available at pyralux.dupont.com. Pyralux® FR flexible circuit materials DO NOT contain polybrominated biphenyls (PBBs), polybrominated biphenyl oxides (PBBOs), or polybrominated diphenyl ethers (PBDEs).

DuPont™ Pyralux® FR

Flame Retardant Acrylic-Based Coverlay

Flexible Circuit Materials

Product Performance

Table 2 - DuPont™ Pyralux® FR Coverlay Properties

Property	FR0110 Typical Value	Test Method
Dielectric Constant (Dk) 1 MHz 10 GHz	3.6 3.1	IPC-TM-650 2.5.5.3 ASTM D2520
Loss Tangent (Df) 1 MHz 10 GHz	0.020 0.015	IPC-TM-650 2.5.5.3 ASTM D2520
Peel Strength* (Adhesion to Copper) As Received, N/mm (lb/in) After Solder, N/mm (lb/in)	1.6 (9.0) 1.6 (9.0)	IPC-TM-650 2.4.9
Adhesive Flow, mm (mil)	0.10 - 0.15 (4 - 6)	IPC-TM-650 2.3.17.1 [†]
Dimensional Stability (MD/TD)	± 0.03 %	IPC-TM-650 2.2.4
Solder Float, 288 °C for 10 s	Pass	IPC-TM-650 2.4.13
Volume Resistivity, Ω · cm	> 10 ¹⁵	IPC-TM-650 2.5.17
Surface Resistance, Ω	> 1013	IPC-TM-650 2.5.17

Data within this table are typical values for the listed product. Performance can vary depending on construction and processing.

Quality and Traceability

DuPont™ Pyralux® FR Coverlay is manufactured under a certified ISO9001:2015 Quality Management System facility. Complete material and manufacturing records, which include archive samples of finished product, are maintained by DuPont. Each manufactured lot is identified for reference traceability. The packaging label serves as the primary tracking mechanism in the event of customer inquiry and includes the product name, batch number, size, and quantity.



pyralux.dupont.com

For more information on DuPont™ FR Coverlay or other DuPont products, please visit our website.

The information provided in this data sheet corresponds to our knowledge on the subject at the date of its publication. It may be subject to revision as new knowledge and experience becomes available. This information is not intended to substitute for any testing you may need to conduct to determine for yourself the suitability of our products for your particular purposes. Since we cannot anticipate all variations in end-use and disposal conditions, DuPont makes no warranties and assumes no liability in connection with any use of this information. It is intended for use by persons having technical skill, at their own discretion and risk. Nothing in this publication is to be considered as a license to operate under or a recommendation to infringe any patent right.

CAUTION: Do not use in medical applications involving permanent implantation in the human body. For other medical applications, see "DuPont Medical Caution Statement," H-50102-5 and "DuPont Policy Regarding Medical Applications" H-50103-5..

DuPont", the DuPont Oval Logo, and all products, unless otherwise noted, denoted with ", "" or " are trademarks, service marks or registered trademarks of affiliates of DuPont de Nemours, Inc. Copyright © 2020 DuPont de Nemours Inc. All rights reserved.

EI-10114 (3/20)

^{*}Lamination Conditions: 14 kg/cm² (200 psi) at 182 °C (360 °F) for 1 hour to treated side of 1 oz RA copper foil.